

TECHNICAL DATA


ROLF BENZ 310



**ROLF
BENZ**

- Wooden inner frame
- Nosag spring support
- Back in polyurethane foam
- Seat in polyurethane foam, built up in coordinated layers varying in height and firmness
- Cover quilted underneath with non-woven polyester
 - Steel brace options:
 - stainless steel
 - painted RAL 9017 traffic black









! Wave formation and depressions in the seat area are unavoidable, due to comfort and design reasons, even in high quality Rolf Benz upholstered furniture.
All measurements are approximate.



Armchair







Sofa

Seat heights available






**ROLF
BENZ**


Sectional sofa*





Corner modular sofa element*





Sectional sofa





Corner sectional sofa*





Sectional sofa with fixed footstool*





Corner sectional sofa with fixed footstool*




Upholstered bench




Footstool




Combination examples:



ASO 310/195 le.
E-ARB 310/217 le.
ASO 310/195 ri.



ARB-PSZ 310/231 le.
E-ASO 310/224 ri.



ASO 310/195 ri.
E-ASO 3140/224 le.

*These elements are only shown in the left version. They are also available in the right version.

**ROLF
BENZ**